



Bluetooth PTT for Zello

Bluetooth type PTT for connecting POC APPs

Type: Bluetooth PTT

Operating Temp: -20°C±2°C ~ 50°C±2°C Storage Temp: -40°C±2°C ~ 80°C±2°C

Approx. Weight: 14.5g

Specification

Fully Qualified Bluetooth v2.1

Chip set: CSR BC5 + 16MB external Flash

Receiver Sensitivity: -82 dBm (typ.)

PTT function built-in

Power class 2,10 meters

Display: Two color LED

Support: SPP Profile

DC Input: 5 VDC (std.)

DC Current: 16 mA (avg.)

DC Current: 20 mA (transient)

Battery: 240mAh

Use Time: 15 Hours (MAX)

Charging Type: USB




User Manual (Android)

1. Press the PTT button and then hold down the power button. When the LED of PTT-220-VZ flashes 2 times every second, it is in the pairing mode now.




2. Get in "Settings – Bluetooth" on the smartphone (take LG smartphone for example) and wait for the "PTT-220" to be found. Select "PTT-220". Though the "PTT-220" doesn't show "connecting", it is normal.

(NOTE: if the PTT-220-VZ lost the link with "Zello". Go to settings power off/on Bluetooth again.)






- 3. To set "Push-to-talk buttons" before using the PTT-220-VZ for "Zello" app:
 - a. First, open the "Zello" app, and click the three dots at the upper left.
 - b.Next, select the "Options".





c. Third, select the "Push-to-talk buttons" and click the "Add" button. When the popup window of "Press and release..." is displayed, press the PTT button on PTT-220-VZ, and it will be connected with "Zello" app.





d.Last, the "PTT-220 (Hold to talk)" should display in the window. When you press the PTT button on the PTT-220-VZ, the LED will be red. Now you can use the PTT-220-VZ to work with "Zello" app.

